

User manual

UVC UV germicidal lamp



During the work of this product, it is forbidden to have people or animals or plants present to avoid burns or other injuries caused by ultraviolet radiation. If there are high-value items (such as antiques, calligraphy and other valuables) in the disinfection space, please remove the related items In this space or do the corresponding shielding protection to avoid ultraviolet or ozone to find out the damage of items.

Part parameters and functions		packing list	
Rated voltage	220V	Product	X1
Rated frequency	50HZ	Remote controller	X1
Rated Power	38W	User Manual	X1
UV Wavelength	254nm		
Timing mode	Electronic timing		
Remote control:	10 meters wireless remote control		
Light tube Quality standards	GB/T 19258-2012		


Precautions:

1. During the work of this product, People, animals, plants and valuables are not allowed to be present, so as not to be injured by ultraviolet rays.
2. Before using this product, please keep the surface of the

UV lamp clean and tidy. If there is dust or dirt on the surface of the lamp, it should be removed with alcohol in time to prevent the effect of sterilization.

3. After using product, keep it ventilated for 15–30 minutes to prevent damage to people, animals, plants and objects after using this product.

Panel operation instructions

Touch key	Features	Description
	Turn on / off the light	After turning on the power, "⏻" Indicator light is on, touch one time "⏻", Select sterilization for 15 minutes. Touch two times "⏻", Select sterilization for 30 minutes, Touch three times "⏻", Select sterilization for 60 minutes; If you make a mistake, you can click to select again. Press "⏻" for 3 seconds, Forced cancellation
	Time setting confirmation	

Remote operation instructions:

- 1, After turning on the power, press "⏻" on / off button to turn on /off the lamp.
- 2, Choose 15 minutes' sterilization if press 15' button
- 3, Choose 30 minutes' sterilization if press 30' button
- 4, Choose 60 minutes' sterilization if press 60' button